



**TEL ☐ 1-866-XANATOS**

# **INSTALLATION INSTRUCTIONS**

**PART#: 7G020206SS\7G020206A  
TAIL LIGHT GUARD FOR HUMMER H3 06-09**

## TAIL LIGHT GUARD FOR HUMMER H3 06-09

- 2- SUPPORT BRACKETS
- 2- # 6 x 1/2 SCREWS
- 4- 1/4 FLAT WASHERS

- STEP 1. UNSNAP REAR PLASTIC CAP TO ACCESS THE EXISTING SCREW. PROCEED TO LOOSEN SCREW ONLY DO NOT REMOVE ( SUPPORT BRACKET WILL SLIDE ONTO THE EXISTING SCREW)  
DRIVER SIDE SHOWN - REPEAT ON PASSENGER SIDE
- STEP 2. PULL ON REAR PLASTIC MOLDING JUST ENOUGH TO SLIDE SUPPORT BRACKET TO ATTACH TO THE EXISTING SCREW.  
DRIVER SIDE SHOWN - REPEAT ON PASSENGER SIDE
- STEP 3. SNUG TIGHT SUPPORT BRACKET TO THE EXISTING SCREW.  
DRIVER SIDE SHOWN - REPEAT ON PASSENGER SIDE
- STEP 4. REMOVE THE EXISTING SCREWS ATTACHING TAIL LIGHT LENS (THIS WILL ALLOW TO ANGLE THE TAIL LIGHT LENS ON DRIVER SIDE ONLY.)  
DRIVER SIDE SHOWN - REPEAT ON PASSENGER SIDE
- STEP 5. ATTACH TAILLIGHT GUARD (REAR DOOR MUST BE HALF WAY OPEN AND TAIL LIGHT LENS MUST BE AN ANGLE POSITION TO ALLOW TAILLIGHT GUARD TO SLIDE ON DRIVER SIDE ONLY. )  
DRIVER SIDE SHOWN - REPEAT ON PASSENGER SIDE
- STEP 6. PROCEED TO TIGHTEN EXISTING SCREWS PREVIOUSLY REMOVED.  
DRIVER SIDE SHOWN - REPEAT ON PASSENGER SIDE
- STEP 7. TIGHTEN EXISTING SCREW THROUGH THE REAR PLASTIC MOLDING HOLE.  
(LEAN BRACKET 1/8" TO THE LEFT AND TIGHTEN DRIVER SIDE ONLY.)  
DRIVER SIDE SHOWN - REPEAT ON PASSENGER SIDE
- STEP 8. TIGHTEN SUPPORT BRACKET TO THE TAILLIGHT GUARD USING # 6 x 1/2 SCREWS.  
(IT MAY BE NECESSARY TO PULL ON TAILLIGHT GUARD SLIGHTLY TO THE LEFT TO LINE UP BOTTOM HOLE ON TAILLIGHT GUARD ON DRIVER SIDE ONLY.)  
DRIVER SIDE SHOWN - REPEAT ON PASSENGER SIDE



Step 1



Step 2



Step 3



Step 4



Step 5



Step 6



Step 7



Step 8



Passenger Side Shown