



TEL ☐ 1-866-XANATOS

INSTALLATION INSTRUCTIONS

PART#: 8BA20SS / 8BA20A (Double Tube)

REAR BUMPER GUARD FOR MERCEDES BENZ ML SERIES 98-05

PARTS LIST:

-
1. 1 - REAR BUMPER GUARD
 2. 4 - 1/2-12×3.5HEX HEX HEAD BOLT
 3. 4 - 1/2"-13 NYLOCK NUT
 4. 4 - 1/2" ×13×φ35 WASHER
-

ASSEMBLY:

1. READ THE WHOLE INSTRUCTION BEFORE BEGINNING.
2. INSERT THE PROVIDED BOLTS OF THE REAR BUMPER GUARD TO THE EXISTING HOLES OF VEHICLE FRAME RAIL.IT IS POSSIBLE TO LOCATE BY HOLDING THE REAR BUMPER GUARD ALIGN WITH THE VEHICLE BUMPER.THE REAR BUMPER SHOULD BE ASSEMBLE OUTSIDE OF THE FRAME RAIL.
3. BOLT THE REAR BUMPER WITH BOLTS, LOCKNUTS AND WASHERS PROVIDED☐
4. ADJUST AND TIGHT UP ALL THE BOLTS FOR COMPLETE INSTALLATION.

