



**INSTALLATION INSTRUCTIONS**  
**APPLICATION □ 96-00 TOYOTA RAV-4**

TEL:1-866-XANATOS

**MOUNT KIT**  
**B16**

QTY	PARTS KIT CONTENTS DESCRIPTION	TOOLS REQUIRED
1	MOUNT BRACKET-DRIVER SIDE	PHLIIPS SCREW FRIVER 17 MM SOCKET 3/4" WRENCH `3/4" WRENCH TOROUÉ WRENCH PATCHET
1	MOUNT BRACKET-PASSENGER SIDE	
2	M12×50 HEX BOLT	
2	Φ12 FLAT WASHERS	
2	Φ12 LOCK WASHERS	
4	M10×25 HEX BOLT	
4	Φ10 FALT WASHER	
2	Φ10 LOCK WASHER	

- STEP1: REMOVE THE CONTENTS FROM THE BOX AND CHECK FOR ANY DAMAGE. VERIFY ALL PARTS AGAINST PARTS LIST.
- STEP2: READ AND UNDERSTAND INSTRUCTIONS COMPLETELY BEFORE BEGINNING INSTALLATION.
- STEP3: INSTALL MOUNT BRACKET USING BOTTOM 10MM BOLT, FLAT WASHER, AND LOCKWASHER AS SHOWN IN FIG 1. LEAVEL LOOSE.
- STEP4: REMOVE LOWER FASCIA MOUNT SCREWS. (LOCATED JUST TO THE OUTSIDE OF TOW HOOKS.) PULL FASIA AWAY SLIGHTLY TO ACCESS TOP BOLT HOLES. (FIGURE 2)
- STEP5: FASTEN TOP OF BRACKET USING 10MM FASTENERS (FIGURE 2)
- STEP6: MOUNT SAFARI BAR USING M10 FASTENERS. (SEE FIG 3 TO 4)
- STEP7. CENTER AND LEVEL SAFARI BAR. TIGHTEN AND TORQUE FASTENERS AS LOSTED. M12 FASTENERS TO 65FT.LBS, M10 -32 FT.LBS