



BLACK HORSE OFF ROAD®

Installation Instructions

Auto Safe

Part# ASDR01 Fits: Ram Trucks 2011-2018

Hardware Contents:

4 x Self-Tapping Screws

Tools Needed:

Phillips Screwdriver





Installing the Safe

STEP 1 Empty the armrest box of all its contents.

STEP 2 Insert the safe into the armrest box.

a. Keep the safe door open to ensure the safe is inserted into the armrest box correctly.

STEP 4 Insert the 4 Self-Tapping SCREWS into the 4 holes in the safe base, **DO NOT OVERTIGHTEN**, over tightening may result in armrest/ safe damage.

STEP 5 Replace the padding in the floor of the safe.

Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided.