



## **BLACK HORSE OFF ROAD®**

### **Installation Instructions**

#### **Workhorse Auto Safe Part# ASFF01**

**Fits: - FORD F150 (WITH FULL FLOOR CONSOLE) & RAPTOR PLATINUM 2012-2014**

#### **Parts List:**

#### **Accessories:**

- 4 Self-Tapping Screws
- 4 Nuts

#### **Tools:**

- Open-end Wrench
- Center Punch
- Phillips Screwdriver





## Installation

**STEP 1** Empty the armrest box of all contents including the mat at the bottom.

**STEP 2** Place the top panel of the safe into the armrest box. Open the lid and try to place the panel on the top of the armrest box.

**STEP 3** Put the brackets into the armrest box through the safe door. Note there are **two studs** on both sides of the top panel. Check that the pre-drilled holes in the brackets align with the screws of the panel.

**STEP 4** Hand tighten the **Nuts** on the studs of the panel, then use an Open-end wrench to tighten. Do not overtighten, overtightening will damage the studs.

**STEP 5** Use the center punch to punch pilot holes through the pre-drilled holes in the brackets.

**STEP 6** Screw the **Self-tapping Screws** through the pilot holes in the safe into the armrest box. Do not overtighten.

## Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided.