



BLACK HORSE OFF ROAD®

Installation Instructions

Workhorse Auto Safe Part# ASFF05

**Fits: 2015-2020 Ford F150, 2015-2022 Ford F250, F350, 2017-2023 Ford Super Duty,
2018-2022 Ford Expedition with Full Floor Console]**

Hardware List:

4 x Self-Tapping Screws

4x Nuts

1x USB Port extension

Tools Needed:

Phillips Screwdriver

Open ended wrench





Safe installation:

STEP 1 Empty the armrest box including the factory mat at the bottom.

STEP 2 Insert the 2 side brackets into the armrest box.

STEP 3 Align the safe lid on top of the brackets so that the pre-drilled holes fit on the threaded studs.

STEP 4 Open the safe lid, screw the acorn nuts on to the exposed threads, then tighten the nuts. Do not overtighten, overtightening may damage the threads.

STEP 5 Screw the 4 self-tapping screws through the 4 pre-drilled holes in the base of the safe into the bottom of the armrest box.

DO NOT OVER-TIGHTEN, over tightening may also result in armrest safe damage.

STEP 6 Plug in the USB Port extension

Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided.