



BLACK HORSE OFF ROAD®

INSTALLATION INSTRUCTIONS

ARMREST SAFE ASGM01

**[2019-2022 Chevy Silverado 1500 / GMC Sierra 1500 and
2020-2023 Chevy Silverado 2500/3500HD / GMC Sierra 2500/3500 HD - Full Console w/ Bucket
Seats]**

Tools Needed:

- **Phillips Screwdriver**
- **Socket Wrench**



[Type here]

Black Horse Off Road Corporate Offices: - 39 St. Mary's Place Freeport NY11529 USA.
Tel: +1 (866) 926-2867 www.blackhorseoffroad.com E-mail:-info@blackhorseoffroad.com



Installing the Safe

STEP 1 Empty the armrest box including the factory mat at the bottom of the console.

STEP 2 Remove the padding from the bottom of the inside of the safe.

tighten the screws, **DO NOT OVER-TIGHTEN**, over tightening will result in armrest safe damage.

STEP 3 Remove the 2 File Holders on each side of the armrest box.

Remove the 4 screws (2 to each side), then the file holders can be removed (these will be re-inserted later)

STEP 4 Use a wrench to remove the **2 BOLTS** from the bottom of the armrest box.

STEP 5 Remove the 2 side brackets from the console safe. To do this, remove the 4 screws (2 on each side), allowing the brackets to be temporarily removed.

STEP 6 Set the safe into the armrest box.

(To ensure the safe is inserted into the armrest box correctly, make sure that the holes in the base of the safe line up with the holes in the armrest box.)

STEP 7 Re-insert the **2 BOLTS** through the holes in the safe into the armrest box.

STEP 8 Use the wrench to tighten the 2 bolts, **DO NOT** over-tighten, over-tightening will damage the console.

STEP 9 Re- Install the safe side brackets, and the two file holders in the armrest box.

Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin.

Please record the combination on the card provided.

[Type here]

Black Horse Off Road Corporate Offices: - 39 St. Mary's Place Freeport NY11529 USA.
Tel: +1 (866) 926-2867 www.blackhorseoffroad.com E-mail: -info@blackhorseoffroad.com