



BLACK HORSE OFF ROAD®

Installation Instructions

Workhorse Auto Safe Part# ASGM05

Fits: - SUBURBAN, TAHOE, YUKON, YUKON XL 2015-2020





Installation:

STEP 1 Empty the armrest box including the factory mat at the bottom.

STEP 2 Pull out **2 PLASTIC FILE HOLDERS** on either side of the armrest box.

- a. These are removed by pulling outward on the center of the tab, then forward towards the front of the console.

STEP 3 Use the wrench to remove the **2 FACTORY BOLTS** from the bottom of the armrest box.

STEP 4 Remove the bottom padding from the inside of the safe.

STEP 5 Insert the safe into the armrest box.

- a. To ensure that the console is correctly installed the 2 holes in the base of the safe should align with the holes in the armrest box.

STEP 6 Re-insert the **2 FACTORY BOLTS** into the armrest box through the pre-drilled holes in the safe.

STEP 7 Use the wrench to tighten the bolts, **DO NOT** over-tighten, over-tightening may damage the console.

STEP 8 Re-insert the 2 file holders that were removed in **STEP 2**.

Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided and keep in a safe place.