



## **BLACK HORSE OFF ROAD®**

### **Installation Instructions**

#### **Workhorse Auto Safe**

**Part# ASTT01   Fits: - TOYOTA TUNDRA 2014 - 2021**

#### **Accessories list:**

**2** x Flat Washers

**1** x USB Port Extension

#### **Tools Needed:**

Socket Wrench





## Installation:

**STEP 1** Empty the armrest box including the factory mat at the bottom.

**STEP 2** Use the wrench to remove the **RIGHT FRONT** and the **LEFT REAR** bolts from the bottom of the armrest box.

**STEP 3** Remove the padding from the bottom of the inside of the safe.

**STEP 4** Lower the safe into the armrest box.

a. Open the safe lid and ensure the safe is inserted into the armrest box correctly, make sure that the holes in the base of the safe line up with the factory holes in the armrest.

**STEP 5** Insert the **SHORTER BOLT** along with **1 WASHER** in the **RIGHT FRONT** screw hole, and the **LONGER BOLT** with **1 WASHER** in the **LEFT REAR** screw hole.

a. When placing the bolts into their respective slots, make sure that the **WASHER** is installed between the bolt and the safe floor.

**STEP 6** Tighten the bolts but , **DO NOT over-tighten.**

**STEP 7** Plug in the USB Port extension

## Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided.