



## **BLACK HORSE OFF ROAD®**

### **Installation Instructions**

#### **Workhorse Auto Safe**

**Part# ASTT02 Fits: - TOYOTA SEQUOIA 2023 – 2023, TUNDRA 2022-2023**

##### **Parts List:**

- **2 pcs Bolts**
- **2 pcs Washers**

##### **Tools Needed:**

- **Socket wrench**
- Setting the lock password**





## Safe installation:

- STEP 1** Empty the back of the armrest box.
- STEP 2** Remove the factory bolts from the bottom of the armrest box.
- STEP 3** Open the lid of the safe and remove the padding from the safe.
- STEP 4** Insert the safe into the armrest box and ensure the pre-drilled holes in the safe align with the holes in the base of the armrest box.
- STEP 5** Use a wrench to install the 2 supplied bolts and washers. Don't over-tighten.
- STEP 6** Re-insert the padding taken from the safe before installation.

## Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided.