



# **BLACK HORSE OFF ROAD®**

## **Installation Instructions**

### **Workhorse Auto Safe**

**Part# ASTT04 Fits: - TOYOTA 4-RUNNER 2010 – 2023**

#### **Tools Needed:**

- Socket Wrench





## Installation:

**STEP 1** Empty the armrest box including the factory mat at the bottom.

**STEP 2** Use a wrench to remove the **2 Bolts** at the bottom of the armrest box.

**STEP 3** Open the safe and remove the padding from the bottom of the inside of the safe.

**STEP 4** Set the safe into the armrest box.

a. Keep the safe open and ensure the safe is inserted into the armrest box correctly, make sure that the holes in the bottom of the safe line up with the factory holes in the armrest box.

**STEP 5** Re-install the factory bolts, **DO NOT over-tighten bolts, over-tightening will damage the console.**

## Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided.