



BLACK HORSE OFF ROAD®

Installation Instructions

Workhorse Auto Safe

Part# ASTT05 Fits: - TOYOTA TACOMA 2005 – 2015

Tools Needed:

- Socket Wrench
- Phillips Screwdriver
- Flathead screwdriver





Installation:

STEP 1 Empty the armrest box including the factory mat at the bottom.

STEP 2 Remove the lid of the armrest box.

- a. Use a Philips screwdriver to unscrew the 6 factory installed screws to remove the trim cap from the underside of the armrest box cover.
- b. Unscrew the 4 factory screws to remove the top lid from the hinge.
- c. Use the flathead screwdriver to carefully pry the trims in both corners and then use the screwdriver to remove the hinge.

STEP 3 Use a socket wrench to remove the **2 BOLTS** at the bottom of the armrest box.

STEP 4 Remove the padding from the bottom of the inside of the safe.

STEP 5 Lower the safe into the armrest box.

- a. Keep the safe open and ensure the safe is inserted into the armrest box correctly, make sure that the holes in the bottom of the safe line up with the factory holes in the armrest.

STEP 6 Use a wrench to tighten the bolts, **DO NOT over-tighten bolts, over-tightening will damage the armrest box.**

STEP 7 Re-install the lid of the armrest box.

Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided.