



**INSTALLATION INSTRUCTION**  
**PART# BB094805-SP/BB094805A-SP**  
**BULL BAR FOR 99-06 TOYOTA TUNDRA/01-06 TOYOTA SEQUOIA**

TEL 1-866-XANATOS

QTY.	CONTENT
1	BULL BAR
2	BRACKETS-PASSENGER & DRIVER SIDE
2	1/2 -13 X 2.00" HEX HEAD BOLT
4	1/2" FLAT WASHERS
2	1/2" LOCK WASHERS
2	M12-1.25 X 30MM HEX HEAD BOLT

STEP 1 REMOVE CONTENTS FROM BOX AND VERIFY ALL PART ARE PRESENT. READ INSTRUCTIONS COMPLETELY BEFORE BEGINNING.

STEP 2 IT MAY BE NECESSARY TO REMOVE/RELOCATE FRONT LICENSE PLATE AND LICENSE PLATE BRACKET. IT IS NOT REQUIRED, BUT STRONGLY RECOMMENDED.

STEP 3 DETERMINE PASSENGER AND DRIVER BRACKETS. SEE FIGURE 1. REMOVE AND DISCARD TIE DOWN LOOP AND TOW HOOK, (SAVE SHORTER 12MM FASTNERS). ATTACH BRACKETS USING SHORTER EXISTING FASTENERS AND SUPPLIED 12MM BOLTS AS SHOWN. LEAVE LOOSE.

STEP 4 ATTACH BULL BAR TO BRACKETS USING 1/2" FASTENERS AS SHOWN. LEVEL AND ADJUST BULL BAR AS DESIRED. TORQUE ALL FASTENERS TO 65 FT .LBS.

FINISH PROTECTION- PRODUCTS HAVE A HIGH FINISH THAT MUST BE MAINTAINED SUCH AS ANY OTHER HIGH FINISH PRODUCT ON THE VEHICLE. PROTECT THE FINISH WITH A NON-ABRASIVE AUTOMOTIVE WAX. THE USE OF SOAP, POLISH, OR WAX THAT CONTAINS ABRASIVES IS DETRIMENTAL, AS THE COMPOUNDS SCRATCH THE FINISH AND OPEN IT TO CORROSION.

DISCLAIMER- BUYER ASSUMES ALL RISK AND LIABILITY WHATSOEVER FROM THE INSTALLATION AND USE OF PRODUCTS. PRODUCTS ARE SOLD AS DECORATIVE ACCESSORIES AND SHOULD NOT BE RELIED UPON AS PROTECTION FOR THE VEHICLE OR OCCUPANTS IN THE EVENT OF A COLLISION OR ROLL OVER.

