



TEL: 1-866-XANATOS


INSTALLATION INSTRUCTIONS

**EPIC RUNNING BOARD
07-18 1500, 07-19 25-3500 SILVERADO/SIERRA CREW CAB
INCLUDES DIESEL W/DEF**

PART# E0585

PARTS LIST:

| | | | |
|----|--|----|----------------------------------|
| 2 | SE5 Sidebars | 17 | 8mm x 25mm Hex Bolts |
| 7 | Mounting Brackets | 16 | 8mm T-Bolts |
| 1 | Passenger/Right Upper Mounting Bracket | 33 | 8mm x 24mm OD x 2mm Flat Washers |
| 1 | Passenger/Right Lower Mounting Bracket | 33 | 8mm Lock Washers |
| 8 | Plastic Covers | 16 | 8mm Hex Nuts |
| 16 | Plastic Clips | 15 | 8mm Clip Nuts |
| 1 | 8mm Bolt Plate | 1 | 8mm Nylon Lock Nut |



PROCEDURE:

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ON MODELS WITH DEF TANK, SELECT A FLAT, LEVEL AREA FOR INSTALLATION. MAY REQUIRE CUTTING.

1. Start the installation under the Driver/Left side of the vehicle. Locate the 5 tabs along the bottom edge of the body, (pinch weld). Mounting Brackets will bolt to the 1st, 2nd, 4th and 5th mounting tabs, **(Figure 1)**. Directly above each tab is a top mounting location on the side of the rocker panel. Hold a Bracket up in place to help determine the mounting holes to use.

2. Determine the correct procedure for your model year and each Bracket location.

Bottom mounting location on the edge of the pinch weld.

Flat tab on pinch weld with factory installed weld nut:

Thread hex bolt into weld nut from the backside-down to clear paint from threads.

Flat tab on pinch weld with hole:

Select (1) 8mm Clip Nut. Slide the Clip Nut over the tab with the nut facing up behind the tab, **(Figures 2 & 3)**. Line up threaded nut with hole in the tab. Repeat for each mounting location.

Locate top mounting location on the back side of the rocker panel.

Models with factory installed threaded insert in rocker panel:

Thread 8mm Hex Bolt into threaded insert to clear paint as required, **(Figures 2 & 3)**.

Large and small hole in side of body panel:

Remove the rubber plug from the larger hole, **(Figure 4)**. Select (1) 8mm Clip Nut. Slide the Clip Nut into the larger hole. Line up the threaded nut with the smaller hole.

3. Select (1) Mounting Bracket. Attach the Mounting Bracket to the Clip Nuts or the factory threaded holes with (2) 8mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers, **(Figure 5)**. Do not tighten hardware.
4. Select (1) Plastic Cover. Attach the Cover to the Mounting Bracket with (2) Plastic Clips, **(Figure 6)**.

5. Repeat **Steps 1—4** to attach the (3) remaining Mounting Brackets to the Driver/Left side, **(Figure 1)**.
6. Select (1) SE5 Sidebar. Insert (8) T-Bolts into the channels in the bottom of the Sidebar, (4) per channel, **(Figure 7)**. Attach the Sidebar to the Mounting Brackets with (8) 8mm Flat Washers, (8) 8mm Lock Washers and (8) 8mm Hex Nuts, **(Figure 8)**. Do not tighten hardware
7. Move to the Passenger/Right side of the vehicle. Determine if the vehicle is equipped with a plastic diesel exhaust fluid (DEF) tank, **(Figures 9—11)**.

Models without DEF tank, skip to Step 8.

Models with DEF tank: The tank sits close to the side of the body. With specialized tools, the Passenger/Right Front Upper and Lower Mounting Brackets can be installed but room is very limited. Determine model year of vehicle before proceeding.

Up to 2016 models:

It may be easier to drop the tank down to access the inner side of the body panel for upper bracket installation. Tank will not need to be removed, only dropped down for access to mounting location.

IMPORTANT: If tank is full, it will be very heavy and assistance is highly recommended to avoid injury or damage to the vehicle or the tank. It is recommended that installation is performed when the DEF tank is low on fluid before dropping the tank.


- a. On models with plastic lower tray under the tank, remove the (3) hex bolts attaching the tray to the frame, **(Figure 9)**, and remove the tray.
- b. Release the tank filler hose. Release the plug for the sending unit on the top of the tank.
- c. Support the tank with a floor jack. Place a smooth flat surface, (wooden block for example), between the floor jack and the tank to avoid damaging the plastic tank. Do not push up on the tank; only support the weight of the tank with the jack.
- d. Remove the (2) bolts securing the tank straps to the vehicle, **(Figure 10)**. Tilt the straps to release from the brackets. Slowly lower the tank until the top of the tank is almost visible. Use blocks or stands to support the tank while installing the Front Upper and Lower Brackets.
- e. Proceed to **Step 8**.

On 2017 models and on:

- a. If necessary, remove the (4) hex bolts attaching plastic cover to DEF tank, **(Figure 11)** and remove plastic cover for better access. **NOTE:** On 2017-on 2500/3500 models, only remove plastic cover from DEF tank. **Do not lower DEF tank** and proceed to **Step 8**.
8. Locate the first tab on the edge of the pinch weld. Select the passenger/right front Upper Bracket, **(Figure 12)**. Repeat **Steps 2 & 3** to attach the Passenger/Right Upper Mounting Bracket to the side of the rocker panel, **(Figure 13)**. Do not tighten hardware.
9. Line up the hole in the bottom of the Upper Bracket with the hole in the tab on the pinch weld.
 - a. **Models with a weld-nut:** Slide the Bracket over the weld-nut, **(Figure 13)**. Attach the Lower Mounting Bracket to the bottom of the pinch weld and weld-nut with (1) 8mm Hex Bolt, (1) 8mm Lock Washer and (1) 8mm Flat Washer, **(Figure 14)**. Do not tighten hardware.
 - b. **Models with flat tab and hole:** Insert the 8mm Bolt Plate down through the hole in the Upper Mounting Bracket and mounting tab, **(Figures 15 & 16)**. Attach the Lower Bracket to the bottom of the body and Bolt Plate with (1) 8mm Flat Washer and (1) 8mm Nylon Lock Nut. Leave loose at this time, **(Figure 17)**. Do not tighten hardware at this time.
10. Line up the side tab on the Lower Bracket with the threaded hole in the side of the Upper Bracket. Attach the Lower Bracket to the Upper Bracket with (1) 8mm Hex Bolt, (1) 8mm Lock Washer and (1) 8mm Flat Washer, **(Figures 14 & 17)**. Leave loose at this time.
11. Repeat **Steps 1—4** to attach the remaining (3) Mounting Brackets to the Passenger/Right rocker panel.
12. **For 2017 2500/3500 DEF tank models:** Locate the 2nd mounting location along the bottom edge of the body, (pinch weld), **(Figure 1)**. Hold the DEF cover in place and mark the 2nd Bracket location onto the cover, **(Figure 18)**. Use a sharp knife or hacksaw blade to carefully cut a slot in the plastic cover to clear the 2nd Bracket, **(Figure 19)**. Remove as little plastic as possible.
13. Repeat **Steps 5 & 6** to attach the Passenger/Right Sidebar.
14. Once the Sidebar has been attached and all hardware fully tightened, reinstall the DEF tank and cover, if equipped, as described in **Step 7**.
15. Do periodic inspections to the installation to make sure that all hardware is secure and tight.


To protect your investment, Do not use any type of polish or wax that may contain abrasives that could damage the finish. Mild soap may be used also to clean the Sidebars.

Driver/Left Side Installation Pictured




(Fig 1) Driver/Left (4) mounting locations

Factory 8mm threaded
insert in body panel




(Fig 2) Driver/Left Front mounting location

Factory 8mm threaded
insert in body panel




(Fig 3) Driver/Left Center mounting location

Driver/Left Side Installation Pictured




(Fig 4) Driver/Left Rear mounting location


(2) 8mm Hex Bolts
(2) 8mm Lock Washers
(2) 8mm Flat Washers
(2) 8mm Clip Nuts




(Fig 5) Attach (1) Mounting Bracket to the Driver/Left front mounting location



(Fig 6) Attach (1) Plastic Cover to the Mounting Bracket with (2) Plastic Clips




(Fig 7) Insert (6) T-Bolts into the channels in the bottom of the Sidebar, (3) per channel




(2) 8mm Flat Washers
(2) 8mm Lock Washers
(2) 8mm Hex Nuts

(Fig 8) Attach (1) Sidebar to the driver/left side Mounting Brackets


Remove (2) factory bolts to remove tank straps



(Fig 10) 07-16 Passenger side DEF tank and cover





(Fig 9) 07-16 Passenger side front pictured with DEF tank cover. Remove (3) hex bolts to remove cover




(Fig 11) 2017-on Passenger side pictured with DEF plastic tank cover. If needed, remove (4) hex bolts to remove plastic cover.

Passenger/right Front Installation Pictured



8mm Hex Bolt
8mm Lock Washer
8mm Flat Washer




(Fig 14) For models with welded nut in the pinch weld

8mm Hex Bolt
8mm Lock Washer
8mm Flat Washer



(Fig 15) 8mm Bolt Plate


Passenger/Right Front Installation Pictured




(Fig 16) On models with flat tab, insert 8mm Bolt Plate (Fig 14) down through Upper Bracket and mounting tab

8mm Hex Bolt
8mm Lock Washer
8mm Flat Washer

8mm Bolt Plate
8mm Flat Washer
8mm Nylon Lock Nut



(Fig 17) For models with a hole in the pinch weld



(Fig 18) 2017-on Passenger side DEF cover marked for trimming



(Fig 19) 2017-on Passenger DEF cut for example only