INSTALLATION INSTRUCTION

OEM Running Board For

- 2007 2009 Mercedes-Benz ML320
- 2006 2009 Mercedes-Benz ML500
- 2008 2011 Mercedes-Benz ML550
- 2007 2011 Mercedes-Benz ML63 AMG
 - 2006 2011 Mercedes-Benz ML350
 - 2010 2011 Mercedes-Benz ML450

PART # RMW164



Attention:

- Please read this installation menu before installing this part. Protect your car properly in case there is any scratch might happen.
- You may need to periodically to re-tighten all hardware for safety use after installation.
- Installation pictures are only for your reference, there might be some differences between pictures and real parts but no affection for your fitting.

INSTALLATION PROCEDURE

Step 1: Check if there is any problem with the running board.



Step 2: Remove the side protection to vacate the screws.



Step 3: Install the supporting on the screws and tighten up it with factory nuts.





Step 4: Install the running board on the supporting, and tighten up it with screws.





Step 5: Complete the installation.

INSTALLATION PICTURE



Disclaimer: Caused due to improper installation and use or the related problems and losses, is beyond our company's quality assurance.