



BLACK HORSE OFF ROAD®

Installation Instructions

Auto Safe Part # UASGM05

2014 to 2019 Chevrolet Silverado and GMC Sierra 1500 with an underseat console bench seat. as well as the 2015 to 2020 Chevrolet Silverado and GMC Sierra 2500 and 3500 Series models with underseat console bench seats. This model fits in the center section compartment under the seat of the split bench models of these vehicles.

Note: this model will not fit the 2014 HD trucks (2500 and 3500)

Parts List:

4 Self Tapping Screws

1 Auto Safe

Tools Needed:

Center punch

Phillips Screwdriver





Installation

STEP 1 Open the storage box under the middle seat cushion and empty all contents.

STEP 2 Insert the safe into the storage box.

STEP 3 Use the center punch to poke holes in the wall of the storage box through the 4 pre-drilled holes in the safes.

STEP 4 Insert the 4 self-tapping screws into the punched holes. ***DO NOT OVER-TIGHTEN***

Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided and keep in a safe place.