



INSTALLATION INSTRUCTIONS
APPLICATION □ 92-98 JEEP GRAND CHEROKEE

TEL:1-866-XANATOS

MOUNT KIT
B39

QTY	PARTS KIT CONTENTS DESCRIPTION	TOOLS REQUIRED
2	MOUNT BRACKET	13MM SOCKET
2	ADAPTER BRACKET	15MM SOCKET
2	NUT PLATES (PASSENGER, DRIVER)	18MM WRENCH
4	M12×60N HEX BOLT	9/16" SOCKET
2	M12×50 HEX BOLT	3/4" SOCKET
4	M12 HEX NUT	3/4" WRENCH
10	Φ12 SAE FLAT WASHERS	RATCHET
6	Φ12 LOCK WAHERS	3" EXTENSION
4	M10×25 HEX BOLT	
4	Φ10 FLAT WASHER	
4	Φ10 SPLIT LOCK WAHSEK	

STEP1: REMOVE THE CONTENTS FROM THE BOX AND CHECK FOR ANY DAMAGE. VERIFY ALL PARTS AGAINST PARTS LIST.

STEP2: READ AND UNDERSTAND INSTRUCTIONS COMPLETELY BEFORE BEGINNING INSTALLATION. **NOTE:** IF YOUR VEHICLE IS EQUIPPED WITH FACTORY TOW HOOKS, YOU WILL NEED TO REMOVE THEM, LEAVING THEIR BRACKETS IN PLACE BEFORE PROCEEDING.

STEP3: REMOVE HORNS ON PASSENGER SIDE USING 13 MM SOCKET.
VEHICLE WITHOUT TOW HOOKS

STEP4: INSTALL BRACHETS USING M10 FASTENERS AND NUT PLATES AS SHOWN IN FIGURE 1.2 AND 3. LEAVE LOOSE. (BEND NUT PLATES TO ACHIEVE PROPER ALIGNMENT WHEN PLACING INSIDE THE FRAME. NUT PLATES SHOULD LINE UP HOLES A AND B IN FRAME. SEE FIGURE 2 AND 3. PROCEED TO STEP 7.
VEHICLE WITH TOW HOOKS

STEP5: INSTALL ADAPTER BRACKETS USING ORIGINAL FASTENERS. SEE FIGURE 4.5 AND 6.

STEP6: INSTALL TOW HOOKS AS SHOWN IN FIGURE 6. STRAIGHTEN TOW HOOKS (SEE STEP 8).

STEP7: MOUNT SAFARI BAR USING M12 FASTENERS AS SHOWN IN FIGURE 3 AND 4.

STEP8: CENTER AND LEVEL SAFARI BAR. TIGHTEN AND TORQUE FASTENERS AS LISTED.

M12 FASTENERS TO 65FT.LBS, M10 -32 FT.LBS.
STEP9: REPLACE HORNS.