

BLACK HORSE

TAPE ON RAIN GUARDS INSTALLATION INSTRUCTIONS





STEP 3: Remove Tape Liner



STEP 4: Attach visor to window trim



STEP 5: Repeat steps for other windows

NOTE:

Warranty is void in the event of damage or loss arising from improper installation or application.

For all other issues, please call us for technical support at 718-777-6519 or 718-777-0092 or email us at tech@blackhorseoffroad.com