







## Installation Instructions Vehicle Safe Part Number ASGM02

### ***2023-24 GMC Sierra 1500 and Chevrolet Silverado 1500***

Contents			
Quantity	Part Number	Description	Image
2	HSM6	30mm Hex M6 Screws	
2	WSHR	Washers	
2	RSPC	Rubber Spacers	
1	GM02SMB	Safe Main Body	

- 1- **Clear Center Console:** Remove all items from the center console, including the body mat located at the bottom.
- 2- **Remove OEM Screws:** Remove the (2) OEM screws from the bottom of the console.
- 3- **Remove brackets:** Pull plastic brackets by hand from the left and right sides of the console.
- 4- **Position Main Body:** Place the Main Body into the console, guiding the Main Body to slide it past the bracket mounts.
- 5- **Secure the Main Body:** Screw the 30mm M6 bolts with the washers through the mounting holes in the bottom of the Main Body.
- 6- **Place the foam pad:** Place the foam pad in the bottom of the in-vehicle safe.