

# INSTALLATION INSTRUCTIONS

ASFE20

[2018~2024 Ford Explorer]

Thank you for purchasing our products! Please contact us for any issues!

## Parts List:

- 4 pcs M4\*19 Self Tapping Screws

- **Tools Needed:**

- Punching cone
- Phillips Screwdriver

**Note 1** When you receive this product, we recommend that you check the accessories before the instructions.

**Note 2** The password codes or fingerprints should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

## Safe installation

**STEP 1** Open the armrest box and empty all contents.

**STEP 2** Set the safe into the armrest box.

**STEP 3** Use the punching cone to poke small holes in the wall of the armrest box through the reserved holes of the safes.

**STEP 4** Hand the Self-tapping screws into the reserved holes of the safe and use a screwdriver to tighten the screws into the armrest box. **DO NOT OVER-TIGHTEN THESE SCREWS, THIS COULD DAMAGE THE ARMREST BOX.**

**STEP 5** Enjoy your purchase! Any issues please contact us!