

INSTALLATION INSTRUCTIONS

ASTC18

[for Toyota Camry 2018-2024]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 4 pcs Bolts
- 4 pcs Washers

Tools need:

- Socket wrench

Note 1 When you receive this product, we recommend that you check the accessories before the instructions.

Note 2 The password codes or fingerprints should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

STEP 1 Clear out the contents of the armrest box now, including the factory mat at the bottom of the armrest box.

STEP 2 Remove the 4 Bolts at the bottom of the console compartment.

STEP 3 Open the safe door. Clear out the padding from the safe.

STEP 4 Set the safe into the armrest box. Make sure the reserved holes at the bottom of the safe should line up the factory holes of the armrest box.

STEP 5 Handed the bolts into the reserved holes of the safe.

STEP 6 Use the wrench to tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**

STEP 7 Re-insert the padding that was removed from the safe before installation.