

# INSTALLATION INSTRUCTIONS

ASTH20

[ for Toyota Highland 2020 to 202 ]

Thank you for purchasing our products! Please contact us for any issues!

## Accessories List:

- 4 PCS Self-Tapping Screws
- 4 PCS Stainless Steel Screws

## Tools Needed:

- Phillips Screwdriver
- punching cone

**Note 1** When you receive this product, we recommend that you should check the accessories before the installation.

**Note 2** The password should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

## Safe Installation:

**STEP 1** Clear out the contents of the center console for now, including the factory mat at the bottom of the armrest box.

**STEP 2** Place the two side brackets into the armrest box, pay attention to the brackets, the right, and left brackets are different.

**STEP 3** Put the top panel of the safe on the brackets, find out the reserved holes of the panel, and make the reserved holes of the panels are line with the holes of the brackets.

**STEP 4** Hand the stainless-steel crews in the reserved holes of the panel, and use the Phillips Screwdriver to tighten the panel with the brackets.

**STEP 5** Use the punching cone to poke holes through reserved holes of the brackets into the armrest walls, and hand the Self-tapping screws into the holes, use a Phillips screwdriver to tighten the screws.

**STEP 6** Enjoy your purchase!

**DO NOT OVER-TIGHTEN, over-tightening will result in armrest box damage.**