



## INSTALLATION INSTRUCTIONS

### APPLICATION □ 92-98 JEEP GRAND CHEROKEE

TEL:1-866-XANATOS

#### MOUNT KIT

#### B39

| QTY | PARTS KIT CONTENTS<br>DESCRIPTION | TOOLS REQUIRED |
|-----|-----------------------------------|----------------|
| 2   | MOUNT BRACKET                     | 13MM SOCKET    |
| 2   | ADAPTER BRACKET                   | 15MM SOCKET    |
| 2   | NUT PLATES (PASSENGER, DRIVER)    | 18MM WRENCH    |
| 4   | M12×60N HEX BOLT                  | 9/16" SOCKET   |
| 2   | M12×50 HEX BOLT                   | 3/4" SOCKET    |
| 4   | M12 HEX NUT                       | 3/4" WRENCH    |
| 10  | Φ12 SAE FLAT WASHERS              | RATCHET        |
| 6   | Φ12 LOCK WASHERS                  | 3" EXTENSION   |
| 4   | M10×25 HEX BOLT                   |                |
| 4   | Φ10 FLAT WASHER                   |                |
| 4   | Φ10 SPLIT LOCK WASHER             |                |

STEP1: REMOVE THE CONTENTS FROM THE BOX AND CHECK FOR ANY DAMAGE. VERIFY ALL PARTS AGAINST PARTS LIST.

STEP2: READ AND UNDERSTAND INSTRUCTIONS COMPLETELY BEFORE BEGINNING INSTALLATION. **NOTE:** IF YOUR VEHICLE IS EQUIPPED WITH FACTORY TOW HOOKS, YOU WILL NEED TO REMOVE THEM, LEAVING THEIR BRACKETS IN PLACE BEFORE PROCEEDING.

STEP3: REMOVE HORNS ON PASSENGER SIDE USING 13 MM SOCKET.  
VEHICLE WITHOUT TOW HOOKS

STEP4: INSTALL BRACKETS USING M10 FASTENERS AND NUT PLATES AS SHOWN IN FIGURE 1-2 AND 3. LEAVE LOOSE. (BEND NUT PLATES TO ACHIEVE PROPER ALIGNMENT WHEN PLACING INSIDE THE FRAME. NUT PLATES SHOULD LINE UP HOLES A AND B IN FRAME. SEE FIGURE 2 AND 3. PROCEED TO STEP 7.  
VEHICLE WITH TOW HOOKS

STEP5: INSTALL ADAPTER BRACKETS USING ORIGINAL FASTENERS. SEE FIGURE 4-5 AND 6.

STEP6: INSTALL TOW HOOKS AS SHOWN IN FIGURE 6. STRAIGHTEN TOW HOOKS (SEE STEP 8).

STEP7: MOUNT SAFARI BAR USING M12 FASTENERS AS SHOWN IN FIGURE 3 AND 4.

STEP8: CENTER AND LEVEL SAFARI BAR. TIGHTEN AND TORQUE FASTENERS AS LISTED.

---

M12 FASTENERS TO 65FT.LBS, M10 -32 FT.LBS.  
STEP9: REPLACE HORNS.