



INSTALLATION INSTRUCTIONS
BLACK MODULAR GRILL GUARD
FOR TOYOTA 4RUNNER 96-98/TACOMA 98-00
PART # 17T80202MA

PARTS LIST:

1	Front Bar	6	7/16" x 1-1/4" Hex bolts
2	Frame Brackets	12	7/16" Hex nuts
12	7/16" Flat washers		

INSTALLATION OF BOTTOM FRAME BRACKET

Remove tow hooks from front of vehicle.

Using the bolts that held the tow hooks in place (two bolts per hook) attach the mounting bracket as per the diagram below. Do not fasten bolts too tightly to allow you to adjust the alignment.

INSTALLATION OF FRONT BAR

Line up the three holes on the lower portion of the front bar with the three holes on the frame mounting brackets (outer edge). Using the 7/16" Hex bolts, nuts and washers, fasten the front bar to the mounting brackets, leaving loose for adjustment.

Once the front bar is attached to the mounting brackets, align until satisfied with fit and balance, and tighten all fasteners.

NOTE: It is advisable to re-check all fasteners for tightness after one week.

