



TEL ☐ 1-866-XANATOS

# **INSTALLATION INSTRUCTION**

**PART#:CBB-TOD1109SP**  
**BULL BAR FOR TOYOTA TACOMA**  
**05-15**

## ATTENTION

- ≡ Read the instructions completely before you begin the installation. NOTE: Pictures are for reference only, actual brackets may be different. Installation is the same.
- ≡ You may need to periodically to re-tighten all hardware, such as one month or two month.

## PART LIST

No.	Name	Qty	Remarks	No.	Name	Qty	Remarks
①	Bull bar	1		⑥	Flat washer(big)	2	10mm
②	Bracket (left and right)	2		⑦	Spring washer	6	10mm
③	Hex bolt	2	M10×120	⑧	Hex nut	6	10mm
④	Hex bolt	4	M10×30	⑨	Spacer washer	4	12mm
⑤	Flat washer	10	10mm				

