



# **BLACK HORSE OFF ROAD®**

## **Installation Instructions**

### **Workhorse Auto Safe**

**Part# ASGM09 Fits: Chevy Tahoe, Suburban & GMC Yukon, Yukon XL, Denali 2021~2024**

#### **Hardware contents:**

2 pcs Rubber mat

2 pcs Bolts

2 pcs Washers

#### **Tools Needed:**

Socket wrench





## Installing the Safe

**STEP 1** Empty the armrest box including the factory padding at the bottom.

**STEP 2** Use the wrench to remove the **2 FACTORY BOLTS** from the bottom of the armrest box.

**STEP 3** Place the rubber mats over the reserved holes at the bottom of the armrest box.

**STEP 4** Place the safe into the armrest box. To ensure that 2 holes in the base of the safe should align with the holes in the armrest box.

**STEP 5** Use a wrench to tighten the bolts with the washers. DO NOT over-tighten, over-tightening may damage the console.

**STEP 6** Place the padding in the floor of the safe.

## Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided and keep in a safe place.