

TEL: 1-866-XANATOS

INSTALLATION INSTRUCTIONS

BLACK MODULAR GRILL GUARD FOR TOYOTA TACOMA 2024-2025

PART # 17A096404MA

PROTECTED BY ONE OR MORE PATENT

Before Installation

- Please read the instruction completely for easy installation, which will also help you to avoid scratches or other potential damages to your appealing car.
- The information shown here is for reference only and may differ from the product that you
 receive, however the goods are fitted in the same way.

Care and Cleaning

- Mild soap may be used also to clean the Product.
- Please periodically check and retighten all the hardware and clean the investment for a refresh look.


Parts list

NO.	QTY	PICTURE	NO.	QTY	PICTURE		
1	1	Front Guard	2	1	Left Brush Guard		
3	1	Right Brush Guard	4	1	Driver/Left Side Top Bracket		
(5)	1	Passenger/Right Side Top Bracket	6	1	Driver/Left Side Frame Mounting Bracket		
7	1	Passenger/Right Side Frame Mounting Bracket	8	2	T Bolt (M10x40 Button Head Bolt) (55x16-17-5)		

	_	BLACK MOD	ULAR C	RILL GU	JARD FOR TOYOTA TACOMA 2024-2025
9	2				
		PVC Plastic Retainer φ10 (δ0.7*40*40)			

Standard Parts:

NO.	NAME	QTY	REMARK	NO.	NAME	QTY	REMARK
10	Flat Washer	16	D8 (8x24x2mm)		Nylon Lock Nut	8	M8
12	Button Head Bolt	8	M8_25	13	Flat Washer	18	D10_27_3
14	Lock Washer	10	D10	(15)	Hex Bolt (Full Thread)	6	M10_35
16	Button Head Bolt	2	M10_35	(7)	Hex Nut	10	M10
18	Allen Wrench S=5	1	S=5				




STEP 1:


Remove contents from box. Verify all parts are present. Read instructions carefully before starting installation. Do not attempt installations alone, personal injury or damage to the truck may result.

STEP 2:


1. Follow (Fig 1-7) to remove front clip from vehicle, then remove shutter veins. After, replace front clip to vehicle.




holding front clip to vehicle




(Fig 2) Unplug wire harness




holding front clin to vehicle




(Fig 3) Remove clips and peel wheel well liner from vehicle





(Fig 7) Remove bottom two shutter veins from front clip, then reattach front clip to vehicle








(Fig 6) Pull Bumper from sides and forward to detach from vehicle


BLACK MODULAR GRILL GUARD FOR TOYOTA TACOMA 2024-2025


2. Follow (Fig 8 – 19) to attach Support and Frame Mounting Brackets, the attach Grille Guard to Brackets. Complete each step on both Passenger and Driver side. Ensure all hardware is hand tightened at this point.
















(Fig 13) Remove hardware from lower **Frame Mounting Bracket mounting point**




Mounting Bracket











(Fig 16) Attach Grille Guard to Frame Mounting Bracket





3. Install Brush Guards to Front Guard (Fig 20)



4. Ensure Grille Guard is level, and then tighten all fasteners. Installation is complete. Do periodic inspections to the installation to make sure that all hardware is secure and tight.



NOTE

Any damages and losses caused by improper installation and application, goes beyond our quality warranty.