

INSTALLATION INSTRUCTIONS

PART #7G098606SS/7G098606A TAIL LIGHT GUARD FOR TOYOTA FJ CRUISER 07-09

PARTS LIST:

TEL 1-866-XANATOS

- (1) TAILIGHT GUARD DRIVER SIDE
- (1) TAILIGHT GUARD PASSENGER SIDE
- (2) END BRACKETS
- (2) #6 X 2/3 SHEET METAL SCREWS PHIL PAN HEAD
- (3) #8 X 3/4 SELF TAP PHIL HEAD SCREW
- 2 M3 FLAT WASHER
- 3 M5 FLAT WASHER

PROCEDURE:

- 1- REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY.
- 2- TEMPORARILY REMOVE EXISTING SUB WOOFER LOCATED ON PASSENGER SIDE AND SET ASIDE. SEE FIG. #1.
- 3- LOCATE AND REMOVE PLASTIC SIDE PANEL. LOOSEN HEX NUTS BEHIND TAIL LIGHT ON PASSENGER SIDE. SEE FIG #2
- 4- LOOSEN THIRD HEX NUT THROUGH THE LARGE INTERIOR SIDE PANEL OPENING THAT IS EXPOSED AFTER REMOVING THE SUB WOOFER. SEE FIG. #3
- 5- PULL OUT TAILIGHT GUARD UNTIL YOU HEAR THE TAILIGHT POP OUT. INSERT (1) END BRACKET IN BETWEEN TAILIGHT AND BODY OF VEHICLE ADJUST AND PUSH TAILIGHT GUARD BACK IN. PASSENGER SIDE SHOWN. SEE FIG. #4.
- 6- HAND TIGHT THIRD HEX NUT FOR SNUG FIT. SEE FIG. #3
- 7- REMOVE DOOR STRIKER LOCATED ON PASSENGER SIDE AND INSTALL PASSENGER TAIL LIGHT GUARD. LEAVE LOOSE. SEE FIG. #5
- 8- ATTACH END BRACKET TO TAILIGHT GUARD USING (1) #6 X 2/3 SHEET METAL SCREW PHIL PAN HEAD AND LEVEL AND ADJUST TAILIGHT GUARD AS DESIRED. TIGHTEN AND TORQUE DOOR STRIKER BOLTS.
- 9- REPEAT PROCEDURES #3, 4, 5, AND 6 ON DRIVER SIDE.
- 10- INSERT DRIVER SIDE TAILIGHT GUARD BETWEEN DOOR AND INNER BODY WALL. ADJUST AND PREMARK HOLES AS DESIRED. SEE FIG. #6
- 11- PREDRILL HOLES WITH SIZE 33 DRILLBIT(#2). INSTALL TAILIGHT GUARD USING (3) #8 X 3/4 SELF TAPING SCREWS (INNER BODY WALL) AND (1) #6 X 2/3 SHEET METAL SCREW PHIL PAN HEAD (END BRACKET). LEVEL AND ADJUST THEN TIGHTEN. SEE FIG. #7.
- 12-RE INSTAL DRIVER AND PASSENGER SIDE PANELS AND SUB WOOFER.

