BLACK HORSE

IN CHANNEL RAIN GUARDS INSTALLATION INSTRUCTIONS

Step 3
REMOVE TAPE LINER

STEP 4
INSERT VISOR INTO WINDOW CHANNEL

NOTE:

Warranty is void in the event of damage or loss arising from improper installation or application.

For all other issues, please call us for technical support at 718-777-6519 or 718-777-0092 or email us at tech@blackhorseoffroad.com