



INSTALLATION INSTRUCTION





OE STYL R RUNNING BOARD FOR FORD EXPLORER 13+















PART# RFOEX-11

NOTICE:


- ≡ The figures here are for reference only and may have differences with the actual product you received, however they share the same assembly way.
- ≡ Please read the instruction completely for easy installation, which will also help you to avoid scratches or other potential damages to your appealing car.
- ≡ Please periodically check and retighten all the hardware and clean the investment for a refresh look.

**PART LIST:**

NO.	QTY	PICTURE	NO.	QTY	PICTURE
①	2	 RUNNING BOARD (L&R)	②	2	 FRONT BRACKET 1 (L&R)
③	4	 FRONT BRACKET 2 (L&R)	④	2	 REAR BRACKET 1 (L&R)

⑤	2	 REAR BRACKET 2 (L&R)	⑥	2	 MIDDLE BRACKET
⑦	6	 T-BOLT M8*30	⑧	6	 PLASTIC BLOCK φ8
⑨	4	 T-BOLT M10 (60*16-15)	⑩	4	 PLASTIC BLOCK
⑪	6	 SPRING WAHSERD8	⑫	6	 BIG FLAT WAHSER D8
⑬	6	 HEX NUT M8	⑭	10	 BIG FLAT WAHSER D10
⑮	10	 SPRING WASHER D10	⑯	10	 HEX NUT M10
⑰	4	 SELF-TAPPING THREAD ST4.8_16	⑱	8	 SELF-TAPPING THREAD ST4_12

INSTALLATION DIAGRAM




INSTALLATION INSTRUCTION


Step 1: Please make sure all the parts are available. (symmetry)

Step 2: Install bracket


1. Remove all plugs as following picture and find corresponding holes




2. Insert T bolt and plastic block as following picture showing




2. Install bracket 2 as following picture showing, left and right are same way for installation






Install rear bracket 2 and lock it with spring washer D8 +flat washer D8+hex nut M8 (just loosely lock while not tighten at this time)

Position A from PIC 2



Install middle bracket 2 and lock it with spring washer D8 +flat washer D8+hex nut M8 (just loosely lock while not tighten at this time)



Position B from PIC 2



Install front bracket 2 and lock it with spring washer D8 +flat washer D8+hex nut M8 (just loosely lock while not tighten at this time)


Position C from PIC 2

4. Install bracket 1 as following picture showing, left and right are same way for installation




Install rear bracket 1 and lock it with spring washer D10 +flat washer D10+hex nut M10 (just loosely lock while not tighten at this time)

Position A from PIC 3



Install middle bracket and lock it with spring washer D10 +flat washer D10+hex nut M10 (just loosely lock while not tighten at this time)



Position B from PIC 3




Install front bracket
and lock it with spring
washer D10 +flat
washer D10+hex nut
M10 (just loosely lock
while not tighten at
this time

Position C from PIC 3

Step 3: According to the following installation diagram, install the running board to front&middle and rear brackets with the Accessories. Notice to adjust running board to appropriate position and then tighten all the bolt and nut.



Step 4: Tighten the self of tapping screw thread the two ends as the following fu



Step 5: Adjust and tighten all spare parts, repeat above steps for another side

Step 6: Installation finished.

Disclaimer: Problem and damage out of the inappropriate installation and use is exclusive of our warranty.