



INSTALLATION INSTRUCTIONS

PART#:BB150503\BB150503A

2.5" BULL BAR FOR


2013 2016 Acura RDX

2007 2016 Honda CR-V

TEL 1-866-XANATOS

PARTS LIST:

1	Sport Bar	4	12-1.75mm x 35mm Hex Head Bolt
1	Driver Mounting Bracket (A)	6	12mm Nylock Nuts
1	Passenger Mounting Bracket (B)	12	12mm Flat Washer
2	12-1.75mm x 60mm Hex Head Bolt		



PROCEDURE:

1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY.
2. Using a flat screwdriver carefully remove all fasteners from factory plastic shroud underneath the vehicle. There are (4) on the front and (3) on each side by the fender (Figure 1
3. Remove plastic shroud and place it on a working area. Using a hack saw; carefully cut the driver side marked area shown in Figure 5.
4. Reposition factory plastic shroud with fasteners removed in step 2.
5. From underside of vehicle, locate and remove the passenger and driver factory sub frame bolts located on the outer side of plastic shroud (Figure 2 & 3).
6. Position Passenger Side Mounting Bracket as shown in Figure 2 and secure it with factory bolt removed in step 5. Do not tighten at this time.
7. Use the included (1) 12-1.75mm x 60mm Hex Head Bolt, (1) 12mm Nylock Nut, and (2) 12mm Flat Washers to attach the second mounting hole on the bracket to the existing hole on the sub-frame of the vehicle (Figure 2). Do not tighten at this time.
8. Repeat steps 6-7 for driver side.
9. Mount Sport Bar on the inner side of Mounting Brackets (Figure 4). Use the included (4) 12-1.75mm x 35mm Hex Head Bolts, (4) 12mm Nylock Nuts, and (8) 12mm Flat Washers to attach Sport Bar to both mounting brackets.
10. Once the Sport Bar is fully mounted on vehicle, level and adjust Sport Bar; then tighten all hardware at this time.
11. Do periodic inspections to the installation to make sure that all hardware is secure and tight.




Figure 1

